How to Setup T.38 Fax

1. Open grandstream page
   - Hint. Can call *** then enter 02 to obtain IP address
2. Click on FXS Ports tab
   1. Update the following values to the following
   2. Primary SIP Server: sbc.simplelogin.net
   3. SIP User ID: Copy from Portal
   4. Authenticate ID: Copy from Portal
   5. Authenticate Password: Copy from Portal
   6. Name: Fax1
   7. Register expiration: 5
   8. Disable Call-waiting: NO
   9. Disable Call-waiting Caller ID: NO
   10. Disable Call-waiting tone: NO
   11. Perferred Vocoder (in listed order)
      1. PCMU
      2. G729
      3. G722
      4. Fax Mode: T.38
      5. Jitter Buffer Length: High
      6. Click Update
      7. Click Apply
      8. Click Reboot
   12. Go back to portal
   13. turn on Caller ID Override & set to fax number.
   14. Assign or purchase numbers

Revision #1
Created 2026-06-21 04:45:43 UTC by DC Tech Staff
Updated 2026-06-21 04:46:22 UTC by DC Tech Staff