

Worldwide Push-To-Talk Radios

- [Application Quick Reference Guide](#)
- [G Radio 2-Way Portable LTE Push to talk \(PTT\) Radio Manual](#)

Application Quick Reference Guide

Setup Instructions

1. Go to the app store and search for POC Global
2. Open the application
3. Enter the account number and password given by the DC Tech
4. Once Logged in, Click settings
5. Click change password (Note: Password can only be 8 alphanumeric characters long.)

Group Feature

This is the main screen you will always see when your application opens. Here you can choose from the many voice chat groups available. If you have paid for personal private channel programming those groups will appear on the public social channels. By default, you are entered into social CH1 or your private CH group when opening the application. Just click on a different channel and you will enter the new group and a prompt will let you know you're on the new channel.

Once you're on your desired group channel you will see a list of members.



User name



RA_R



RA_RO



RA_D



RU_D



RU_RI



MU_C



MU_RO



Blue members are currently active in the group chat

Orange Members are active in our groups

Grey Members are currently offline from the group network

Push to Talk

Let the conversations begin. Introduce yourself by pressing and holding down the blue PTT button found

at the center bottom of the application, once you press the button wait 3 seconds before speaking and

then you have up to 60 seconds (some channels 30 seconds) to voice your conversation.

9:26



social CH1



User name



RA_R



RA_RO



RA_D



RU_D



Speaking...



MU RO









After you are done speaking release the PTT button and listen to the conversation, when it is your turn to speak press and hold the PTT button and speak. It is that simple.

Key takeaway: If someone else is speaking you will not be able to talk over them, they must finish their transmission before you can speak, crowded channels may be harder to speak in so you may consider trying a different channel.

Example of someone else speaking:

social CH1

Group name

	All members	5/18
	social CH1	5/18
	social CH10	5/18
	social CH11	5/18
	RA_RO	5/18
	TRSpeaking...	5/18

TRSpeaking...

Additional Settings:

Voice Menu:

1. Volume Adjustment: The volume of the application can be adjusted either by your volume buttons on your iPhone or on your screen.

Voice Broadcast: If authorized is used for channel hosts presenting a live show that requires continuous transmission. To register as a show host contact us

Show Menu:

1. Start speak prompt: This feature enables a beep before you start talking.

2. Network speed: This shows how much data is being used by your phone.

3. Switch account: If you have more than one talk2me social account, you can switch between accounts.

4. Exit: You can log out of the application.

G Radio 2-Way Portable LTE Push to talk (PTT) Radio Manual

Device Introduction

The DC Tech G Radio Portable LTE PTT Radio can provide VOD services (Voice over data) to almost any location utilizing cellular broadband technology. Fast, reliable and private communications are now just a simple click of the push to talk button provides continuous connectivity for voice communications.

Package Contents

- G0 Radio Portable LTE PTT Radio
- 1 x Pre-Installed Nano SIM card
- 1 x Headset Microphone Cable
- 1 x USB Power Adapter
- 1 x USB-C Cable

SIM Card Information

A SIM Card WILL be preinstalled in the radio

DO NOT REMOVE THE SIM CARD unless told to do so by a support team member.




Now that you know your buttons we power on the radio, all other functions will be discussed later in this manual.

Power On/Off key (Red back key)

- Push in and hold the Power button for 3 seconds to turn on the radio.
- Push in and hold the Power button for 3 seconds to turn off the radio.

Once the radio has powered up you will be taken to the main display screen below:



Front Panel Display Screen

The radio displays status information on the front panel. (From top to bottom)

1. Signal strength: Displays tower radio signal strength.
2. Connected Technology: Displays radio network type.
3. SIM Slot: Displays current slot in use.
4. SOS: When the SOS red icon is displayed, the SOS feature is available. Go to SOS features page for more information.
5. GPS Icon: When the GPS icon is displayed it means the feature is activated, when the icon turns green it means that radio unit has GPS connectivity, see GPS features for more information.
6. Battery Icon: Shows current battery levels, more detailed battery information can be found in the radio's settings menu.
7. Headset Icon: When displayed this means radio audio is going through the earpiece/microphone headset.
8. Group Icon indicates current group channel.
9. Member Icon indicates your current member's ID name.
10. Service provider indicates current radio network being used.

11. Speaker Icon: Idle means listening to the channel, Red Speaker Icon:

Member indicates current member speaking.

12. Time and Date indicates current date and time from the tower.

Functions of the Radio



1. PTT (Push to talk button on microphone). - The large push to talk button is located on hand microphone and is easy to use. Just press and hold for 1 second before you start talking and then hold while transmitting your message and then release when done.

2. Vol+/Vol- - These buttons control the volume of the radio and also are the up and down selectors for any options.

3. Menu - This button allows you to display and select the available options such as settings, members and groups.

3. OK - This button acts as the confirm button for entry changes. OK/SOS - This button when held down for 3 seconds will trigger the SOS activation mode, to end SOS just press the same button

again.

4. Power/Exit. – This button allows you to exit any current menu options and also services as the radios off and on button, See Power button for details.

Options Menu

There are 4 options to choose from when pressing the menu button.

A. Group.

B. Member.

C. Settings.

D. Mine.

To choose from any of these options use the Vol+/- buttons on the side of the radio and then hit the OK button to enter the desired menu.

A. Group Menu:

The following option allows you to select the desired GROUP channel you want to enter. Use the Vol+/- buttons on the side of the radio and then hit the OK button to enter the desired group.

B. Member Menu:

The following option allows you to select the desired member you want to have a 1 on 1 private conversation with. Use the Vol+/- buttons on the side of the radio and then hit the OK button to select the desired member. Reminder that the member must be online to communicate with.

C: Settings Menu:

The following options will help you customize your radio unit. The number

below corresponds with the settings option.

Available options are:

1. Display settings.
2. Volume settings.
3. Keypad Lock settings.
4. Key wakeup settings.

5. Call in wakeup settings.
6. Voice play settings.
7. Power savings settings.
8. Signal value information.
9. Double card SIM card settings.
10. Battery Information.
11. Service Information.
12. GPS Information.
13. IMEI QR Code and Information.
14. Restore factory settings.
15. APN settings.

D. Mine Menu Option

1. SOS - Emergency Call

This feature allows the company dispatcher to know when a radio unit is experiencing an emergency that requires priority attention. Once a radio unit is subscribed to the SOS service a red icon will appear at the top of the radio display screen (see example below):



To activate the SOS Emergency, call on your radio hold down the OK button for 3 seconds and this will automatically send a signal to the company dispatcher and other radio units that the SOS is active and provide other units with location information and your Radio ID for immediate notification, all users in the group with SOS activated will receive this information. It is important that you use this option in conjunction with a company dispatcher account as only the dispatcher software can clear the SOS alert.

2. GPS Device Tracking

This feature allows the company dispatcher or mobile application users to the exact location of the radio units assigned with this feature.

- When the GPS icon is white this will indicate that the GPS is available but unable to receive a signal from the satellite.
- When the GPS icon is green this will indicate that the GPS is receiving a signal from the satellite.

Radio functionality tips.

Features and tips:

Poor and no signal issues:

Note: When in a weak signal environment and with poor call quality, you can choose power save mode or normal mode. The call quality will be improved, but the machine also consumes more power.

Automatic screen shutdown:

If there is no button operation within the set time, the radio will automatically shut down the screen.

Transmit prompt sound:

After enabling this function, press and release the PTT key will emit a "beep" prompt sound, which will improve the call experience. When this function is turned off, pressing the

PTT key will result in no prompt sound.